


PSSR 5.4 – What you need to know about changes

Roles that are being split into multiple roles



Work in a Substation



Current Role Held	What will change	Role Details	What you need to do
PSSR 3-3 - Work in a Substation - General	This role will be split into 3 roles		
	PSSR Substations - Work in HV Areas (3.3)	This role is for a person who will perform general work in high voltage areas of a substation. Eg labourer, civil workers, general trades They will not be a Safety Observer or plan movements of mobile plant in HV areas	If you only require this role you do not need to do anything. When your reauthorisation is due you will complete an eLearning course
	PSSR - Safety Observer (8.1)	This role is for a person who will perform the high risk work activity of being a safety observer for mobile plant in high voltage work areas	Discuss with your company – if required complete PSSR Change Request Form and if approved complete issued training by 30 th September 2023
	PSSR - Mobile Plant Assessment (8.2)	This role is for a person who will perform the high risk work activity of planning the movements of mobile plant in high voltage work areas	Discuss with your company – if required complete PSSR Change Request Form and if approved complete issued training by 30 th September 2023

Work in a Substation

Current Role Held	What will change	Role Details	What you need to do
PSSR 5.2 Receipt of a HV Access Authority	This role will be split into 2 roles		
	PSSR - Substations - Receive a HV Access Authority (5.2)	This role is for those needing to receive an access authority in a substation. PSSR - Substations - Supervise Instructed Persons (3.4) will become a prerequisite for this role	Discuss with your company. If you only held the role of PSSR 5.2 to supervise instructed persons you can complete the PSSR Change Request Form to amend your role to PSSR 3.4 You should only hold PSSR 5.2 if your work activities require you to receive HV Access Authority.
	PSSR - Substations - Supervise Instructed Persons (3.4)	This role is separated from PSSR 5.2 to enable a person to supervise instructed persons in a substation HV area with out holding PSSR 5.2. The role is for people who directly supervise the work of others. An electrical qualification is no longer required	Transgrid will consult with your company to confirm role requirements

Work on Transmission Lines

Current Role Held	What will change	Role Details	What you need to do
PSSR 6.1 - Overhead lines and equipment – General	This role will be split into 3 roles		
	PSSR - Transmission Lines - General (6.1)	<p>This role is for a person who will work in the high voltage areas of a transmission line, eg labourer, civil workers, general trades.</p> <p>They will not be a Safety Observer or plan movements of mobile plant in HV areas</p>	<p>If you only require this role you do not need to do anything.</p> <p>When your reauthorisation is due you will complete an eLearning course.</p>
	PSSR - Safety Observer (8.1)	<p>This role is for a person who will perform the high risk work activity of being a safety observer for mobile plant in high voltage work areas.</p>	<p>Discuss with your company – if required complete PSSR Change Request Form and if approved complete issued training by 30th September 2023</p>
	PSSR - Mobile Plant Assessment (8.2)	<p>This role is for a person who will perform the high risk work activity of planning the movements of mobile plant in high voltage work areas.</p>	<p>Discuss with your company – if required complete PSSR Change Request Form and if approved complete issued training by 30th September 2023</p>

Work on Transmission Lines

Current Role Held	What will change	Role Details	What you need to do
PSSR - Transmission - Receive Field Access Authority (6.3)	This role will be split into 2 roles		
	PSSR - Transmission - Receive Field Access Authority (6.3)	This role is for people needing to receive field access authorities	You do not need to do anything. Your role will be transferred to the new roles. When your reauthorisation is due you will complete eLearning.
	PSSR 10.1 - Bridge Earthing transmission Line Structure	This role is for people performing this work activity of bridging earths on transmission line structures.	

Roles with changed training requirements from 1st July for new workers

PSSR Roles with changes to training requirements

PSSR Role	New Training Requirement	What you need to do
PSSR - LV/Mech - General (4.0)	eLearning only	When you register in WSAT you will be required to provide any pre-requisites such as White card and complete eLearning. You will no longer be required to attend a classroom training
PSSR - Work under a HV Access Authority (5.1)	eLearning only	
PSSR - Transmission Lines - General (6.1)	eLearning only	
PSSR- Work under a Field Access Authority (6.2)	eLearning only	

New roles available from the 1st July



New PSSR Roles available from 1st July 2023

PSSR Role	Who the role is for	Prerequisite Roles	How to apply for Role
PSSR Substations - General (3.1)	A person who will work in a substation building or carpark Eg cleaner, labourer, general trades	None	Company admin to apply through WSAT Roles portal
PSSR - Substations - Supervise Instructed Persons (3.4)	A person who needs to supervise people in high voltage areas of a substation. The person should hold a supervisor role for their company. The person should have good verbal communication skills	PSSR Substations - Work in HV Areas (3.3)	Company admin to apply through WSAT Roles portal. Request may include PSSR 3.3 request if person does not hold. PSSR 3.3 has a practical (in person) requirement. This role has a practical (in person) requirement.
PSSR - Safety Observer (8.1)	A person who will perform the high risk work activity of being a safety observer for mobile plant in high voltage work areas	PSSR Substations - Work in HV Areas (3.3) PSSR - Transmission Lines - General (6.1)	Company admin to apply through WSAT Roles portal. The training request will include PSSR 8.1 and PSSR 8.2 and has a practical (in person) requirement.
PSSR - Mobile Plant Assessment (8.2)		PSSR Substations - Work in HV Areas (3.3) PSSR - Transmission Lines - General (6.1) PSSR - Safety Observer (8.1)	Request may include PSSR 3.3 request if person does not hold. PSSR 3.3 and has a practical (in person) requirement.

New PSSR Roles available from 1st July 2023

PSSR Role	Who the role is for	Prerequisite Roles	How to apply for Role
PSSR - Substations - Operate LV/MECH and Carry out LVMPRI/PMWI (4.3R)	The role is for electrical technicians required to perform low voltage/mechanical field operations on the Transgrid network and to perform work activities to carry out LVMPRI/PMWI . Eg Protection technician	PSSR Substations - Work in HV Areas (3.3) PSSR Substations - Receipt of a LV/MECH Access Authority (4.1) Note: An electrical qualification is required	Company admin to make request direct to training@transgrid.com.au
PSSR 10.1 - Bridge Earthing transmission Line Structure	The role is for transmission lines tradespeople who typically conduct maintenance and civil works on structures.	PSSR - Transmission Lines - General (6.1) Note: An electrical qualification is required	Company admin to make request direct to training@transgrid.com.au

PSSR – Switching Roles

PSSR – Field Operations

Field Operation or 'Switching' roles are held by ESI partners.

ESI partners are typically distributors, generators or partners Transgrid has a contract and MOU to deliver switching services for Transgrid's maintenance programs. The roles are not available in the WSAT roles portal.

Current PSSR Role	New PSSR Role	What you need to do
PSSR 6.5R - Operate Switchgear or Connection Point Switching	PSSR - Operate HV apparatus connection point (9.1)	You do not need to do anything. Your role will be transferred to the new naming. When your reauthorisation is due you will complete eLearning.
PSSR 6.5 - Operate HV AIS for work on or near Overhead Lines		